

## **UNWIND & REWIND OPTION**



- Euclid can manufacture special “**Unwind**” and/or “**Rewind**” units that can attach directly to your choice of Euclid Coater.
- Euclid can also manufacture special independent “**Stand-alone**” **Unwind** and **Rewind** units to be used with your existing coating machine ranging from 6” - 36 inches wide.
- Euclid also offers standard 1.00” inch diameter unwind and rewind shafts, as well as special “**Air Expandable Core-Lok**” air shafts for holding your unwind and rewind cores.