

ATP Mixers / Dissolvers



For DISPERSING, MIXING and SOLUBLISHING of solids in liquids. The powerful motor maintains its selected speed, independent of changes in viscosity and this guaranties an optimum dispersion-process. The machine is built together on a steel stand of solid construction, Built in Air Cylinder for easy lifting and lowering of the mixer.

Adjustable speed by means of Frequency Converter (Siemens or ABB), Machine is build according to the latest CE-Standards. Different mixing elements exchangeable

ATP DISSOLVER-MIXER is standard in 4 different models:

- * 3,0 kW Till 100 Litre
- * 4,0 kW Till 200 Litre
- * 5,0 kW Till 300 Litre
- * 7,5 kW Till 400 Litre

Also in flame-proof version available

ATP Mixer

A modern 60 Liter mixer for Crèmes, Lotions and Food applications.



For DISPERSING, MIXING and SOLUBLISHING of solids in liquids. The powerful motor maintains its selected speed, independent of changes in viscosity and this guaranties an optimum dispersion-process.

These High-Tec dissolvers can also be used for making samples and results can be scaled up for production machinery.

The machine is built together on a bench-mounting stand of solid construction, with stainless steel column and counterweight for easy lifting and lowering.

Model : ATP-MIXER® model for 60 litre vessels

Motoroutput : 1,10 kW (1.5 hp)

Speed : 0 - 2200 rpm, infinite adjustable PID electronics ensure constant speed even while viscosity chances

Readout : Digital display, True shaft speed

Timer : Built in timer, adjustable till 100 minutes, automatic stop

Materials : Mixing element and Shaft all in stainless steel.

Vessel fixing : By belt and CE safety switch.

Safety CE : According to the latest safety norms.