


Cotton

A moisture tester is a valuable tool during the ginning process and when buying or selling cotton. Cotton ginned at the appropriate level of moisture produces the longest and strongest fibers.

The newly designed C-2000 utilizes the relationship between moisture content and electrical resistance to effectively measure the moisture content of cotton fibers. Its functionally designed case with built-in handle puts controls at your fingertips.

C-2000	
	<p>Features:</p> <ul style="list-style-type: none">• Microcontroller-based circuit for greater accuracy and reliability• Two separate scales for testing lint cotton or seed cotton• Set point with buzzer to alert you when a pre selected %MC has been reached• Stores up to 100 readings and displays the average and highest of the stored readings• Built-in calibration check <p>Specifications:</p> <ul style="list-style-type: none">• Moisture Range: 4%-16-%, lint cotton; 6%; 20%, seed cotton• Size: 7 1/2" x 3" x 13/4"• Battery: 9V Alkaline• Warranty: 1 year• Carrying Case: included