

Hay Moisture Meter

Proper moisture control at baling is key to reducing mold development, preserving leaves, color and feed value. These factors are critical to the hay producer's main goal – to produce better quality hay and minimize economic losses.

Delmhorst offers models ranging from the popular F-6/6-30 to the advanced FX-2000 which allows you to monitor moisture content while baling. Our assortment of models gives you the opportunity to select the right meter for your application.

FX-2000



Features:

- Microcontroller circuit
- Can be used for on-the-go moisture monitoring or as a portable meter
- **In continuous mode:**
 - Takes two readings every second
 - Displays the average and highest of eight accumulated readings
 - Readings updated every 4 seconds
 - Back lighted display
- **In portable mode:**
 - Averages up to 100 accumulated readings
 - Displays average and highest of accumulated readings
- Measures moisture content over the range of 6%-40%
- Three-year warranty
- Ideal for high volume producers who need the time-saving convenience of on-the-go monitoring

FX-2000 Package Variations:

Individual Instrument: Includes meter with power supply. Order as FX-2000W/PS.

Value Package: Includes meter with power supply, 1986 bale sensor with cable and mounting bracket. Order as FX-2000/1986.

Deluxe Package: Includes meter with power supply, 1986 bale sensor with cable and mounting bracket, H-4 handle, 830-2 10" probe, 831 windrow probe and carrying case. Order as FX-2000/PKG.

Deluxe 18" Package: Includes meter with power supply, 1986 bale sensor with cable and mounting bracket, H-4 handle, 830-3 18" probe, 831 windrow probe and carrying case. Order as FX-2000/18/PKG.

F-2000



Features:

- Microcontroller circuit
- Averages up to 100 accumulated readings
- Displays average and highest of accumulated readings
- Measures moisture content over the range of 6%-40%
- Three-year warranty
- Great for the hay producer who utilizes the memory features for enhanced quality control

F-2000 Package Variations:

Individual Instrument: Includes meter.
Order as F-2000.

Value Package: Includes meter and 1235 10" probe. Order as F-2000/1235.

Deluxe Package: Includes meter, H-4 handle, 830-2 10" probe, 831 windrow probe and carrying case.
Order as F-2000/PKG.

Deluxe 18" Package: Includes meter, H-4 handle, 830-3 18" probe, 831 windrow probe and carrying case.
Order as F-2000/18/PKG.

F-6/6-30



Features:

- Popular analog readout
- Moisture content range from 6% to 30%
- One year warranty
- A favorite among value-minded producers, and those serving the export markets that require lower %MC range readings

*The F-6/6-30 is also available with 13%-40% moisture content range. Please specify F-6 when ordering.

F-6/6-30 Package Variations:

Individual Instrument: Includes meter. Order as F-6/6-30.

Value Package: Includes Meter and 1235 10" probe. Order as F-6/6-30/1235.

Deluxe Package: Includes meter, H-4 handle, 830-2 10" probe, 831 windrow probe and carrying case. Order as F-6/6-30/PKG.

Deluxe 18" Package: Includes meter, H-4 handle, 830-3 18" probe, 831 windrow probe and carrying case. Order as F-6/6-30/18/PKG.